

**Umschlüsselung  
Gehäuselager**
**Ball Bearing Units  
transcoding**

| <b>NBR</b>  | <b>INA</b>                                       | <b>SNR</b>                                   |
|---|--|--|
| UCEF<br>UCEFC<br>UCEFL<br>UCEFLZ<br>UCEP<br>UCESF | RCJY<br>RMEY<br>RCJTY<br>RCJTZY<br>RASEY<br>RCFY | UCFE<br>UCFCE<br>UCFLE<br>UCFLZ<br>UCPE<br>– |
| UKEF<br>UKEFC<br>UKEFL<br>UKEFLZ<br>UKEP<br>UKESF | –<br>–<br>–<br>–<br>–<br>–                       | UKFE<br>UKFCE<br>UKFLE<br>UKFLZ<br>UKPE<br>– |
| SBEF<br>SBEFC<br>SBEFL<br>SBEFLZ<br>SBEP<br>SBESF | PCJY<br>PMEY<br>PCJTY<br>PCJTZY<br>PASEY<br>PCFY | USFE<br>USFCE<br>USFLE<br>USFLZ<br>USPE<br>– |
| SAEF<br>SAEFC<br>SAEFL<br>SAEFLZ<br>SAEP<br>SAESF | PCJ<br>PME<br>PCJT<br>PCJTZ<br>PASE<br>PCF       | ESFE<br>ESFCE<br>ESFLE<br>ESFLZ<br>ESPE<br>– |
| HCEF<br>HCEFC<br>HCEFL<br>HCEFLZ<br>HCEP<br>HCESF | RCJ<br>RME<br>RCJT<br>RCJTZ<br>RASE<br>RCF       | EXFE<br>EXFCE<br>EXFLE<br>EXFLZ<br>EXPE<br>– |
| CSEF<br>CSEFC<br>CSEFL<br>CSEFLZ<br>CSEP<br>CSESF | –<br>–<br>–<br>–<br>–<br>–                       | –<br>–<br>–<br>–<br>–<br>–                   |