



Umschlüsselung Gehäuselager

Ball Bearing Units transcoding

EBS	INA	SNR
UCEF UCEFC UCEFL UCEFLZ UCEP UCESF	RCJY RMEY RCJTY RCJTZY RASEY RCFY	UCFE UCFCE UCFLE UCFLZ UCPE –
UKEF UKEFC UKEFL UKEFLZ UKEP UKESF	– – – – – –	UKFE UKFCE UKFLE UKFLZ UKPE –
SBEF SBEFC SBEFL SBEFLZ SBEP SBESF	PCJY PMEY PCJTY PCJTZY PASEY PCFY	USFE USFCE USFLE USFLZ USPE –
SAEF SAEFC SAEFL SAEFLZ SAEP SAESF	PCJ PME PCJT PCJTZ PASE PCF	ESFE ESFCE ESFLE ESFLZ ESPE –
HCEF HCEFC HCEFL HCEFLZ HCEP HCESF	RCJ RME RCJT RCJTZ RASE RCF	EXFE EXFCE EXFLE EXFLZ EXPE –
CSEF CSEFC CSEFL CSEFLZ CSEP CSESF	– – – – – –	– – – – – –